



ULTRA PREMIUM TIRE GLUE

WEAR EYE PROTECTION WHEN USING THIS PRODUCT.

USE IN A WELL-VENTILATED SPACE.

TIRE BONDING instructions: 1.) Scuff the mounting areas of the tires and wheels with 220-grit sandpaper. If gluing to chrome plated wheels, remove all plating from the tire mounting area. 2.) Clean the tire and wheel mounting areas with denatured alcohol to remove any manufacturing residue and debris from sanding. 3.) Mount the tires to the wheels, making certain tire inserts are in place (if used) and proper tread direction is observed (if the tire has a directional tread pattern). 4.) Gently lift the sidewall of the tire to allow access to the mounting area. 5.) Place a drop of glue into the gap and lower the tire into the mounting area, making sure it seats fully. Do not allow the tire to snap back into place or glue spatter may result. 6.) Repeat, working your way around the tire until glue has been applied to the entire circumference of the tire. 7.) Allow the glue to dry. Check for any gaps by gently pulling on the sidewall and apply glue as needed. 8.) Turn the tire over and repeat steps 4-7.

OTHER USES: If used for bonding items other than wheels and tires, test on a non-essential portion of material to ensure compatibility first. Ensure parts are clean, dry and free from oil and grease. Parts must fit precisely. Apply sparingly to one side and hold parts together until handling strength is achieved. Bonding can be immediate, rapid alignment of parts is required.

STORAGE: Replace cap and tighten securely. Store in a cool area out of direct sunlight. To ensure maximum glue life and performance, refrigerate to 40°F (5°C).

DANGER: CONTAINS CYANOACRYLATE: Avoid contact with eyes and skin. Bonds skin and eyes in seconds. Skin contact through clothing may cause burns. May cause allergic skin reaction. Vapors irritating to eyes, nose and throat.

EYE CONTACT: Do not force eye lids open. Wash with warm water and apply a gauze patch. Seek medical attention.

SKIN CONTACT: Soak in warm soapy water. Avoid use of excessive force to free bonded area. Gently pry fingers apart with the aid of a blunt instrument such as a spoon handle, paper clip or pencil, peeling or rolling the surfaces apart. Call a physician if irritation occurs and persists.

INHALATION: If symptoms occur, remove person to fresh air. Exposure can be limited by use of adequate ventilation.

INGESTION: Adhesive will solidify and adhere to mouth. Saliva will lift the adhesive within 1/2 to 2 days.

KEEP AWAY FROM CHILDREN.

Made in USA



If you have questions or need technical assistance, call Traxxas at

1-888-TRAXXAS

(1-888-872-9927) (U.S. residents only)

Part: #6468

SP12218